



**“GET STIPPLED”**

**Shop Address:**  
84/86 Industry Drive  
Tweed Heads South,  
NSW 2486

**Postal Address:**  
P.O. Box 351,  
Banora Point,  
N.S.W. 2486

**Phone:**  
+61 7 55244 235 or  
+61 7 55233 539

**Fax:**  
+61 7 5524 6940

**Web:** [www.getstippled.com](http://www.getstippled.com)  
**E-Mail:** [info@getstippled.com](mailto:info@getstippled.com)



INTERIOR/ EXTERIOR    WALL AND CEILING    TEXTURE COATINGS

## ULTRATEX TUSCAN SAND

THIS MATERIAL TESTED BY THE CSIRO AND COMPLIES WITH ASINZS 1530.3:1999.

WE GUARANTEE OUR PRODUCTS WHEN USED IN ACCORDANCE WITH OUR COMPLETE SYSTEM AND APPLIED USING THE BEST ACCEPTED TRADE PRACTICES.

### DESCRIPTION:

A 100% acrylic, heavy-duty coating containing various fillers and fines to produce a medium/coarse sandy finish to most masonry surfaces.

### USE ON:

Cement render, tilt-up concrete, AAC blocks and panels, off-form concrete, Harditex sheeting, blueboard, concrete blocks and clay bricks etc (refer to notes on skim-coats patching). Suitable for housing, commercial, high rise, blockwork/blueboard fences and any suitably prepared masonry surfaces.

### COLOUR RANGE:

White, accent and ultra deep bases allows unlimited choice of colours.

### PROPERTIES:

Profile:	Sandy Medium/Coarse
Surface:	Medium/Coarse
Dry film:	Up to 2.5mm at peak
Weather Resistance	Excellent
Solvent:	Water
Odour:	Low (Wet) nil (Dry)

### SURFACE PREPARATION:

Refer notes on SUBSTRATES.

### APPLICATION METHOD # 1. (ROLLED)

1. Apply one coat of ULTRATEX TEXPRIME with a lambswool roller, brush or spray. Allow up to 4 hours to dry.
2. Apply one coat of ULTRATEX TUSCAN SAND with a lambswool roller, brush or spray. Allow 4 hours to dry.
3. Apply one coat of ULTRATEX TUSCAN SAND with a lambswool roller, brush or spray. Allow 4 hours to dry.

### APPLICATION METHOD # 2. (TOSCANI)

1. Apply one coat of ULTRATEX TEXPRIME with a lambswool roller, brush or spray. Allow 4 hours to dry.
2. Apply one coat of ULTRATEX TUSCAN SAND with a lambswool roller, brush or spray and while the product is still wet criss cross with a 100mm brush or tosi brush. Allow 4 hours to dry.
3. Repeat step # 2.

### NOTE:

Application method # 2 can be altered. You could criss cross only one of the top coats to give you less of a pattern.

\*FOR EXTRA PROTECTION USE ONE EXTRA COAT OF ULTRATEX PROTECT SATIN or ULTRATEX SUPAFLEX\*

### PACKAGING:

ULTRATEX TUSCAN SAND is supplied in ready for use re-sealable 4ltr and 15ltr plastic containers.