



"GET STIPPLED"

Shop Address:
84/86 Industry Drive
Tweed Heads South,
NSW 2486

Postal Address:
P.O. Box 351,
Banora Point,
N.S.W. 2486

Phone:
+61 7 55244 235 or
+61 7 55233 539

Fax:
+61 7 5524 6940

Web: www.getstippled.com
E-Mail: info@getstippled.com



INTERIOR/ EXTERIOR WALL AND CEILING TEXTURE COATINGS

ULTRATEX PROTECT SATIN

THIS MATERIAL TESTED BY THE CSIRO AND COMPLIES WITH ASINZS 1530.3:1999.

WE GUARANTEE OUR PRODUCTS WHEN USED IN ACCORDANCE WITH OUR COMPLETE SYSTEM AND APPLIED USING THE BEST ACCEPTED TRADE PRACTICES.

DESCRIPTION:

A 100% acrylic polymeric heavy-duty membrane coating containing various fillers and fines to produce a satin finish to most masonry surfaces. Used as a final coating for most of ULTRATEX'S texture coatings.

USE ON:

Cement render, tilt-up concrete, AAC blocks and panels, off-form concrete, Harditex sheeting, blueboard, concrete blocks, tiled roofs and clay bricks etc (refer to notes on skim-coats patching). Suitable for housing, commercial, high rise, blockwork/blueboard fences and any suitably prepared masonry surfaces.

COLOUR RANGE:

White, accent and ultra deep bases allows unlimited choice of colours.

PROPERTIES:

Profile:	Low
Surface:	Flat
Dry film:	Flat
Weather Resistance	Excellent
Solvent:	Water
Odour:	Low (Wet) nil (Dry)

SURFACE PREPARATION:

Refer notes on SUBSTRATES.

APPLICATION METHOD # 1:

1. Apply one coat of ULTRATEX ULTRAPRIME with a lambswool roller, brush or spray. Allow 4 hours to dry.
2. Apply one coat of ULTRATEX PROTECT SATIN with a lambswool/texture roller, brush or spray. Allow 4 hours to dry.
3. Apply one coat of ULTRATEX PROTECT SATIN with a lambswool/texture roller, brush or spray. Allow 4 hours to dry.

NOTE:

Avoid applying product in direct sunlight or with high winds/rain in the area.

* PLEASE DO NOT USE INFERIOR PRIMER-ALWAYS USE ULTRATEX PRIMERS*

PACKAGING:

ULTRATEX PROTECT SATIN is supplied in ready for use re-sealable 4ltr and 15ltr plastic containers.