



**“GET STIPPLED”**

**Shop Address:**  
84/86 Industry Drive  
Tweed Heads South,  
NSW 2486

**Postal Address:**  
P.O. Box 351,  
Banora Point,  
N.S.W. 2486

**Phone:**  
+61 7 55244 235 or  
+61 7 55233 539

**Fax:**  
+61 7 5524 6940

**Web:** [www.getstippled.com](http://www.getstippled.com)  
**E-Mail:** [info@getstippled.com](mailto:info@getstippled.com)



INTERIOR/ EXTERIOR

WALL AND CEILING

TEXTURE COATINGS

## ULTRATEX EXTERIOR STIPPLE

### DESCRIPTION:

A 100% - acrylic, heavy-duty coating containing various fillers and fines to produce a medium stipple finish to most masonry surfaces.

### USE ON:

Cement render, tilt-up concrete, AAC blocks and panels, off-form concrete, Harditex sheeting, polystyrene foam panels, concrete blocks and clay bricks (refer to notes on skim, patching etc.) Suitable for housing, commercial, high rise, blockwork fences and all suitably prepared masonry surfaces.

### COLOUR RANGE:

White base to accept a vast range of pastel to mid-tone colours.

### PROPERTIES:

Profile:	Medium stipple (black foam texture roller)
Surface:	Coarse
Dry Film:	Up to 3mm at peak.
Weather Resistance:	Excellent.
Solvent:	Water
Odour:	Low (wet) nil (dry)

### SURFACE PREPARATION:

Refer notes on SUBSTRATES.

### APPLICATION:

First Coat: Apply one coat Ultraprime. Allow 8 hours to dry.

Second Coat: Apply one coat Ultratex EXTERIOR STIPPLE with a black foam texture roller to produce a medium stipple. Allow 24 hours to dry.

Third Coat (optional) : Apply one coat Super Flex or Protect Satin with a Lambswool roller at recommended rate of 3.5M2/litre.

### PACKAGING:

Ultratex EXTERIOR STIPPLE is supplied in ready-for-use and resealable 4 Ltr and 15 Ltr containers.



**"GET STIPPLED"**

**Shop Address:**  
84/86 Industry Drive  
Tweed Heads South,  
NSW 2486

**Postal Address:**  
P.O. Box 351,  
Banora Point,  
N.S.W. 2486

**Phone:**  
+61 7 55244 235 or  
+61 7 55233 539

**Fax:**  
+61 7 5524 6940

**Web:** www.getstippled.com  
**E-Mail:** info@getstippled.com



INTERIOR/ EXTERIOR    WALL AND CEILING    TEXTURE COATINGS

## ULTRATEX INTERIOR STIPPLE

THIS MATERIAL TESTED BY THE CSIRO AND COMPLIES WITH ASINZS 1530.3:1999.

WE GUARANTEE OUR PRODUCTS WHEN USED IN ACCORDANCE WITH OUR COMPLETE SYSTEM AND APPLIED USING THE BEST ACCEPTED TRADE PRACTICES.

**DESCRIPTION** .... This product has been the best quality, most economical, interior texture material available since 1985. The only changes made to this winning formula are to keep abreast of the technological advances to the latest acrylic resins, fillers and fungicides. It is completely asbestos free and is not "thick paint" nor is it "plaster". It is a very white, easy to apply, ground-marble based product which can be tinted to any white-based colour.

**APPLICATION** .... All surfaces need to be clean, dry and free of loose materials or form release agents. Imperfections should be filled and the surface primed with our appropriate primer. A black texture roller is recommended to apply the texture and a variety of tools can then be used to achieve many different patterns and effects. One 15 litre drum will cover approximately 30 square metres.

### TRANSPORT / HANDLING / STORAGE AND SAFETY DATA

Supplied in 15 litre, heavy duty, resealable, plastic pails which can be stored up to 5 high, however we recommend that they are transported only 2 high.

APPEARANCE	white paste.
HAZCHEM CODE	non allocated.
FLAMMABILITY	non flammable.
FIRE AND EXPLOSION HAZARDS	nil.
ODOUR	pleasant.
VENTILATION	provide adequate ventilation.

**INGESTION** wash mouth, give water to drink. If severe, seek medical advice.

**EYE CONTACT** flush with copious quantities of water, seek medical advice.

**SKIN CONTACT** may cause skin irritation (wash immediately)  
Not classified as hazardous according to the criteria of Work Safe Australia.  
Not classified as dangerous by the Australian, Dangerous Goods Code.  
Keep containers sealed when not in use. Store in cool place out of direct sunlight.  
Clean up equipment and work area with water in an environmentally friendly manner.  
Where spills occur, soak up with sand, sawdust etc. and dispose of properly.  
Avoid contaminating sewers, drains and waterways.

**IMPORTANT:** Please do not use an inferior primer, always use Ultra Prime.